


For use with the Cashmaster One product range

Space saving integrated printer - fits into
your Cashmaster One device

Small and quiet

More energy-efficient



For use with our new range

Cashmaster **one** **pro** **plus** **max**™

Cashmaster *printer one*

The Cashmaster Printer One for the Cashmaster One product range

The Cashmaster Printer One is smaller, quieter and more energy-efficient than its predecessors. Designed specifically for use with the Cashmaster One range, attach the Cashmaster Printer One with one single click to the base of your device.

No cables or additional worktop space is required, meaning your Cashmaster One device remains fully portable and you can use it whenever you need to.